


MAGNET- Kristallgläser

Set mit 2 Gläsern inkl. 2 Untersetzer



silwy
MAGNETIC DRINKWARE

Bitte lesen Sie vor dem ersten Gebrauch der Gläser und Untersetzer diese Bedienungsanleitung sorgfältig durch. Bedienungsanleitung bitte unbedingt aufbewahren – sie ist Bestandteil der Produkte und muss jederzeit verfügbar sein.

Art.-Nr. 5025-1301-2 // 5020-1302-2 // 5033-1303-2 // 5040-1304-2 // 5025-1305-2

LIEFERUMFANG

2 Kristallgläser mit Magnet // 2 Untersetzer mit Gelbeschichtung
Bedienungsanleitung (dieses Dokument)

WICHTIGE HINWEISE VOR DEM ERSTEN GEBRAUCH

Kristallglas

Reinigen Sie Ihre silwy Gläser gründlich, bevor Sie diese zum ersten Mal benutzen.

Untersetzer

Entfernen Sie vor dem ersten Gebrauch der silwy Untersetzer die Schutzfolien auf der Vorder- und Rückseite.

PRODUKTBESCHREIBUNG

Verwendungszweck

Ein Magnet im Unterboden des silwy Kristallglases findet als Gegenpol entweder einen selbsthaftenden silwy Untersetzer, eine Oberfläche mit silwy Antirutschmatte, die silwy Metallleiste oder einen silwy Tisch, in dem bereits eine metallische Schicht integriert ist. Beide Pole ziehen sich an und das Glas wird fixiert.

Funktionsbeschreibung

Legen Sie die silwy Untersetzer auf einen ebenen Untergrund (beispielsweise einen Tisch) und stellen Sie die silwy Kristallgläser darauf. Mit Hilfe des integrierten Magneten haftet das Glas rutschfest auf dem Untersetzer.

WICHTIG

Verwenden Sie das silwy Kristallglas nur mit den original silwy Untersetzern bzw. weiteren silwy Produkten. Für alle silwy Produkte wurde eine spezielle Anti-Rutsch-Beschichtung entwickelt. Befestigen Sie das silwy Kristallglas nicht an anderen Oberflächen. Wird das silwy Kristallglas während der Fahrt (beispielsweise in Wohnmobilen oder auf Booten) eingesetzt, garantiert die maglassX GmbH keine Anhaftung des Glases auf dem silwy Untersetzer bzw. der weiteren silwy Zubehör-Produkte, insbesondere während und nach einem Bremsvorgang. Ebenfalls kann die maglassX GmbH keine Haftung für ein Überlaufen oder Austreten des Glaseinhalts (beispielsweise Wasser) übernehmen.

Zum Transport der silwy Kristallgläser empfehlen wir die Verwendung der Originalschachtel.

BRUCH

Sollten silwy Kristallgläser durch unsachgemäßen Gebrauch oder äußere Einwirkungen zu Bruch gehen, entsorgen Sie diese bitte umgehend. Sollte der Magnet dadurch freigelegt werden, beachten Sie bitte dringend die Sicherheitshinweise zu den Magneten und entsorgen Sie diesen ebenfalls.

SICHERHEITSHINWEISE

Kleinteile und silwy Untersetzer dürfen nicht unbeaufsichtigt in die Hände von Kindern gelangen: Verschluckungsgefahr bzw. Verletzungsgefahr. Das silwy Glas enthält einen Magneten. Beachten Sie unbedingt die folgenden Warnhinweise zum Magneten:

HAFTUNG

Die maglassX GmbH lehnt jegliche Haftung für Schäden ab, die durch nicht sachgemäße Nutzung/ Handhabung der Magnete entstehen. Falls Sie die silwy Kristallgläser verschenken, legen Sie in jedem Fall diese Warnhinweise bei und weisen auf die Gefahren hin.

Der Einfluss von starken Magneten auf den menschlichen Körper ist umstritten. Man weiß nicht genau, ob die Strahlung heilsam oder schädlich wirkt. Um sicher zu gehen, sollten Sie sich nicht ständig in der Nähe starker Magnete aufhalten. Bewahren Sie die Magnete nicht in Ihrer unmittelbaren Umgebung auf. Magnete erfordern vorsichtigen Umgang. Es besteht Quetschungsgefahr. Freiliegende Magnete nicht bohren, feilen oder sägen.



Magnete können sich auf die Funktion von Herzschrittmachern auswirken. Ein möglichst großer Abstand ist einzuhalten.



silwy Gläser können durch ihre magnetische Kraft spitze, metallische Gegenstände (beispielsweise Besteck) anziehen. Bitte achten Sie deshalb besonders darauf, dass Kinder während der Nutzung von silwy-Produkten beaufsichtigt sind.



Festplatten und EC-Karten sowie weitere elektronische Geräte wie z.B. Fernseher, Monitore, Uhren und Mobiltelefone sind anfällig für starke Magnetfelder. Es droht Datenverlust und Beschädigung der Geräte.



Halten Sie also möglichst hohe Sicherheitsabstände ein (mindestens 1 Meter). Auch dürfen Magnete nicht in der Nähe von Zählern wie z.B. Gaszählern platziert werden.



REINIGUNG

Kristallglas

silwy Kristallgläser sind spülmaschineneeignet (ECO-Modus). Wir empfehlen eine Reinigung per Hand. Bitte verwenden Sie lauwarmes Wasser und ein sanftes Spülmittel.

Untersetzer

Reinigen Sie Ihre silwy Untersetzer nicht mit Scheuerschwämmen oder einer Spülbürste, da die Oberfläche sonst durch Kratzer beschädigt oder stumpf werden kann. Legen Sie die silwy Untersetzer nicht in die Spülmaschine. Sind die silwy Untersetzer längerer Zeit UV-Strahlung ausgesetzt oder lässt ihre Haftkraft nach, reinigen Sie diese vor dem nächsten Gebrauch unter fließendem Wasser und lassen Sie diese trocknen.

ENTSORGUNG

Sollten die silwy Kristallgläser bzw. die silwy Untersetzer einmal nicht mehr benutzt werden, entsorgen Sie diese bitte über den Hausmüll.

GARANTIE

Bei sorgfältiger Behandlung der silwy Kristallgläser, silwy Untersetzer und der weiteren silwy Produkte unter Beachtung der Bedienungsanleitung gewährt der Hersteller 24 Monate Garantie ab Übernahme. Weitere Ansprüche zur Gewährleistung richten sich nach dem Gesetz. Schäden, welche sich aus der unsachgemäßen Benutzung des silwy-Sortiments ergeben, werden nicht ersetzt.

Innerhalb der ersten 24 Monate nach Kaufdatum beseitigen wir die als berechtigt anerkannten Mängel ohne Abrechnung der entstandenen Nebenkosten. Bewahren Sie für eventuelle Garantieansprüche den Kaufbeleg bzw. den Lieferschein mit Lieferdatum auf. Eine etwaige Barauszahlung ist ausgeschlossen.

Für den Reklamationsfall Bedienungsanleitung und Artikelnummer aufbewahren.



EUROPÄISCHE UNION
Investition in unsere Zukunft
Europäischer Fonds
für regionale Entwicklung

Bei Fragen zum Produkt wenden Sie sich bitte an den Hersteller:

maglassX GmbH
DEUTSCHLAND

E-Mail: info@silwy.de
Web: www.silwy.de

MAGNETIC GLASSES

set of 2 glasses incl. 2 coasters



silwy
MAGNETIC DRINKWARE

Please read these instructions for use carefully prior to the first use of the glasses and coasters. Please always keep the instructions for use, since they are an integral part of the products and must be available at all times.

Item no. S025-1301-2 // S020-1302-2 // S033-1303-2 // S040-1304-2 // S025-1305-2

SCOPE OF DELIVERY

2 crystal glasses with magnet // 2 coasters with gel coating
Instructions for use (this document)

IMPORTANT NOTES PRIOR TO FIRST USE

Crystal glass

Thoroughly clean your silwy glasses before you use them for the first time.

Coaster

Prior to the first use of the silwy coasters, remove the protective films on the front and on the rear side.

PRODUCT DESCRIPTION

Intended use

As an opposite pole, a magnet in the bottom of the silwy crystal glass either finds a self-adhesive silwy coaster, a surface with the silwy anti-slip-mat, the silwy metal strip or a silwy table into which a metallic layer has already been integrated. Both poles attract each other and the glass is fixed in place.

Functional description

Place the silwy coasters on a flat surface (a table, for example) and put the silwy crystal glasses on top of them. By means of integrated magnets, the glass sticks to the coaster without slipping.

IMPORTANT

Only use the silwy crystal glass with the original silwy coasters or other silwy products. A special anti-slip coating has been developed for all of the silwy products. Do not fasten the silwy glass to other surfaces. If the silwy glass is used whilst driving (in campers or on boats, for example), maglassX GmbH will not guarantee any adhesion of the glass on the silwy coaster or on other silwy accessory products, especially during and after a braking operation. Furthermore, maglassX GmbH will not accept any liability for any spillage or leakage of the glass content (water, for example).

To transport the silwy glasses, we recommend using the original box.

BREAKAGE

If silwy crystal glasses break due to improper use or external impacts, please dispose of them immediately. If the magnet is exposed as a result of this, please always observe the safety notes regarding the magnets and also dispose of it.

SAFETY NOTES

Small parts and silwy coasters must not be left unattended in the hands of children: Risk of swallowing or risk of injury. The silwy glass contains a magnet. The following warning notes regarding magnets must be observed under all circumstances:

LIABILITY

maglassX GmbH will not accept any liability for damage which is caused by the improper use / handling of the magnets.
If you give the silwy glasses away as a present, be sure to enclose these warning notes and point out the dangers.

The impact of strong magnets on the human body is a controversial topic. It is not clear whether radiation has healing or harmful effects. To be on the safe side, you should not permanently stay near strong magnets. Do not store the magnets in your immediate environment. Magnets require careful handling. There is a risk of crushing. Do not drill, file or saw exposed magnets.



Magnets may interfere with the functioning of cardiac pacemakers. As large a distance as possible must be kept.



Due to their magnetic force, silwy glasses can attract pointed, metallic objects (cutlery, for example). Therefore, please make particularly sure that children are supervised while silwy products are being used.



Hard discs and bank cards as well as other electronic devices such as TV sets, monitors, watches /clocks and mobile phones are sensitive to strong magnetic fields. There is a danger of data loss and damage to the devices.



Adhere to as large a safety distance as possible (at least 1 metre). Magnets must not be positioned near counters and meters, such as gas meters, either.



CLEANING

Crystal glass

silwy crystal glasses are dishwasher safe (ECO-MODE). We recommend cleaning by hand. Please use tepid water and a soft washing-up liquid.

Coaster

Do not clean your silwy coasters using scouring sponges or a washing-up brush, since otherwise the surface might be damaged or become dull because of scratches. Do not place the silwy coasters in the dishwasher. If the silwy coasters have been exposed to UV radiation for a longer period of time or if their adhesion force has decreased, clean them under running water and let them dry prior to the next use.

DISPOSAL

If the silwy crystal glasses or the silwy coasters are no longer used, please dispose of them as normal household waste.

WARRANTY

If the silwy glasses, silwy coasters and other silwy products are handled carefully by complying with the instructions for use, the manufacturer will grant a warranty period of 24 months from the receipt of the products. Further warranty claims will be governed by law. Any damage resulting from the improper use of silwy range of products will not be compensated.

Within the first 24 months from the date of purchase, we will remedy the deficiencies which have been considered justified, without billing the additional costs incurred. For any warranty claims, please keep the receipt or the delivery note with the date of delivery. Any cash payment is excluded.

In the event of a complaint, keep the instructions for use and the item number.



EUROPÄISCHE UNION
Investition in unsere Zukunft
Europäischer Fonds
für regionale Entwicklung

If you have any questions about the product, please contact the manufacturer:

maglassX GmbH
GERMANY

E-Mail: info@silwy.de
Web: www.silwy.de